



## BATTERY CHARGER WITH IP MONITORING

### DIN-rail charger with battery protection and remote monitoring

The JSD-119-XXX/DIN2\_CH\_ODP charger integrates the remote monitoring function and automatic reporting of the monitored power supply parameters. This allows the power supply system to considerably reduce or completely eliminate failures of the powered technology and saves the costs and time of technical maintenance. The power supply system also comprises integrated protection from deep discharge of the battery and features a preset current limit of battery charging, which protects the battery from overcharging.

#### Voltages

Type	Output	Battery current	Disconnecting voltage
JSD-300-138/DIN2_CH_ODP	13,8V/16A	5A	10,5V
JSD-300-275/DIN2_CH_ODP	27,5V/10A	3,3A	21,5V
JSD-300-545/DIN2_CH_ODP	54,5V/5A	1,6A	42V



#### Remote monitoring

Accu voltage, input net, condition of the power supply, accu current, accu temperature

#### Remote control

Power supply switch on/off, output (restart of the connected system)

#### Electrical parameters

Input voltage	160-260 VAC
Input frequency	50/60Hz
Input current	1,7A/230 VAC
Power factor	0,95
Electrical resistance	3000V AC input-output, 1500V AC input-cover
Insulation resistance	Larger as 50MΩ
Ripple of the output voltage	<200mVpp

#### Technical parameters and operating conditions

Operating temperature	-20 to 50°C
Humidity (not condensable)	10 to 80%
Overseas height	up to 2000 mamsl
Enviroment	without explosion
Protection type	IP20
Weight	1,4kg
Cover	Al + FeZn sheet
Dimensions (WxHxD)	70x155x175mm

PS protection class I, overvoltage category EN 61010-1, shortcutproof, designed for continuous operation, T6,3AH/250V fuse on input.

#### Technical norm and certification:

CE declaration of conformity, security EN 60950-1 ed.2, EMC, EN 61000-6-1 ed.2, EN 61000-6-3 ed.2

#### Guarantee 5 years





## REMOTE CONTROL IN BKE POWER SUPPLIES

The monitoring (IP) module used in the BKE power supply unit enables simple and clear monitoring of individual power supply parameters. The module provides information about the general status of the power supply unit, presence of the supply mains and the condition of the protection of the input, output and battery. Battery charging parameters are also monitored - actual voltage, current and temperature and the total current provided by the power supply unit. The possibility of immediately checking the values of these parameters allows engineers to identify the cause of the problems in a particular location before their actual intervention, which helps them avoid or considerably reduce the downtime of the equipment.

The power supply units can be integrated in higher systems using the SNMP protocol, monitored individually via an integrated web interface and they can provide reports about exceeding of monitored parameters by sending e-mail messages. The limit values of the monitored parameters can be customized so that the module can warn the operator in time if an event occurs. E.g. thanks to measurement of the battery voltage the user can be warned in time before its disconnection.

### Alarm configuration

**BKE a.s.**  
Monitor  
Network Settings  
Monitor Configuration  
Restart Monitoring  
Save Settings

IP: 192.168.1.157  
Version: 1.0.16  
**MONITOR CONFIGURATION**  
**MONITOR CONFIGURATION**

	Display	Range Setup		Alarm Value	
		Min	Max	Min	Max
Power Source Current	<input checked="" type="checkbox"/>	0.0	9.4	-1.0	10.0
Battery Voltage	<input checked="" type="checkbox"/>	0.0	56.0	22.0	30.0
Battery Current	<input checked="" type="checkbox"/>	-10.7	10.7	-10.0	3.0
Battery Temperature	<input checked="" type="checkbox"/>	72.0	-5.0	0.0	40.0
Grid State	<input checked="" type="checkbox"/>				
Grid Fuse	<input type="checkbox"/>				
Battery Fuse	<input type="checkbox"/>				
Output Fuse	<input type="checkbox"/>				
Output State	<input checked="" type="checkbox"/>				
Power Source State	<input checked="" type="checkbox"/>				

  
Disconnect Output

**BKE a.s.**  
Monitor  
Network Settings  
Monitor Configuration  
Restart Monitoring

IP: 192.168.1.157  
Version: 1.0.16  
**MONITOR**  
**INPUT**  
Grid: Ok  
Fuse:  
**POWER SOURCE**  
State: Ok  
Current [A]: 0.0  
**OUTPUT**  
Fuse:  
State: Ok  
**DATE AND TIME**  
Time service is not available  
**ACTIVE ALARMS => REPORTS**  
No alarm  
**BATTERY**  
Voltage [V]: 27.8  
Charge Current [A]: 0.3  
Temperature [°C]: 26.4  
Fuse:



### Monitoring via web interface

